

### Parts List

1. EC Jet nozzle body
2. Brass hose barb
3. Brass reducer
4. Quick connect
5. Flat fan nozzle
6. Hose barb
7. Tank screen
8. Plastic ball valve
9. Hose clamp
10. Siphon tube



Contact EaCo Chem to reorder parts  
(800) 313-8505 or [info@eacochem.com](mailto:info@eacochem.com)

### Assembly Instructions

- A. Start with (1)EC Jet nozzle body. Thread the (4)Quick connect into the (1)EC Jet nozzle body on the O-ring side.
- B. Thread the (2)Brass hose barb and the (3)Brass reducer into the (1)EC Jet nozzle body.
- C. Thread the (5)Flat fan nozzle in to the (3)Brass reducer.
- D. Thread the (6)Hose barb into the (10)Siphon tube. Thread the (7)Tank screen onto the opposite side of the siphon tube. Place the (9)Hose clamp onto the longer hose, then insert the (6)Hose barb into the hose and clamp tightly.
- E. Slide (9)Hose clamp on the other end of the longer hose. Insert (8)Plastic ball valve, clamp tightly.
- F. Insert completed (1)EC Jet nozzle body hose barb into one end of the shorter hose, clamp tightly.
- G. Slide (9)Hose clamp on the other end of the short hose and insert (8)Plastic ball valve and clamp tightly. Your EC Jet is now fully assembled.



# EC Jet

Pressure washers equipped with a down stream chemical injector (after the high pressure side) should have the injector removed before using the EC Jet. If the chemical injector is attached with a quick coupler, simply uncouple it and attach the pressure hose in its place. If the chemical injector is hard plumbed in place, simply place the chemical hose in a five gallon bucket full of water when using the EC Jet.



HARD PLUMBED TO PRESSURE WASHER - INSERT HOSE INTO WATER



THE QUICK COUPLING ALLOWS FOR EASY ATTACHMENT TO THE TIP OF YOUR WAND. SIMPLY REMOVE YOUR TIP AND INSERT THE EC JET FOR THE CORRECT UNIT.

